



# Lynx 5210

## *quick reference guide*

1. To set your alarm when leaving home:
  - a. Close doors and windows until a green ready light appears on the security system panel.
  - b. Press the icon that says *ARM AWAY* and enter your four digit user code.
  - c. The keypad will begin to beep. Exit the home, close the door, and lock it behind you.
  
2. To disarm the system when you return home:
  - a. Press the icon that says *DISARM* and enter your four digit user code.
  
3. To set the alarm with a delay when at home:
  - a. Close doors and windows until a green ready light appears on the security system panel.
  - b. Press the icon that says *STAY*, and then enter your four digit user code.
  
4. In the morning, or before opening any protected door or window:
  - a. Press the icon that says *DISARM*, and then enter your four digit user code.
  
5. To set the alarm when at home with no delay (*night mode*):
  - a. Press the icon that says *DELAY*. The security system panel should then read *INSTANT*.
  - b. Press the *STAY* icon and enter your four digit user code.

*Continued on Back*

5. If an alarm has been triggered:
  - a. Before proceeding, verify that the alarm was triggered accidentally. If you aren't sure, wait for the phone call from central station.
  - b. Press the icon that says *DISARM* and enter your four digit user code. This will silence the alarm.
6. Press the icon that says *DISARM* and enter your four digit user code again. This will reset the alarm so that it can be set activated again later.
  - a. The *Monitoring Station* will call you and ask for your password to cancel dispatch of local authorities. If you do not receive a call from the *Monitoring Station* within sixty seconds, call 1-888-745-4733 immediately with your password to cancel dispatch of local authorities.
  - b. To turn the door chime on or off:
    - c. Press the icon that says *MORE*.
    - d. Press the icon that says *SETTINGS*.
7. Press the icon that says *CHIME*. The green light will be on if the chime has been activated or off if it has been deactivated.
  - a. To change your four digit master code:
    - b. Tap on the *MORE* icon.
    - c. Press the *TOOLS* icon and enter your current four digit master code.
8. Tap on the *USERS* icon, then *MASTER* and *EDIT*.
  - a. Under *NAME* is an icon that will display the code.
  - b. Enter your new four digit master code and press *DONE* and *SAVE*.
  - c. Tap the *HOME* button. Your four digit master code has been changed.

*The manufacturer of your security system recommends that you test it weekly to insure that the system is communicating fully with the Monitoring Station in the event that an alarm is triggered. If for any reason you feel your security system is not functioning properly, do not hesitate to call our office at 770-963-0305. We have technicians available to assist you twenty-four hours per day.*